

# 6008 CAREsystem



**VAM – Venous Access Monitor**

**Emergency button**

Initiating four essential steps at once

**OCM® Online Clearance Monitor**

Monitoring the effective dialysis dose

**AutoSub plus**

Enables the automatic maximization of substitution rate

**Streamlined design**

Fewer user actions required

**BVM – Blood Volume Monitor**

Advanced fluid management

**BTM – Blood Temperature Monitoring**

Individual temperature control

**AutoFlow**

Dialysate flow savings

**EcoFlow**

Sensible use of resources